

GLASS HAMMER IN CAPSULES - Vinylester (Epoxy Acrylate)

Code	Size	Hole Diameter	Capsule Length	Capsule Diameter	Fastens Up To	Min Hole Depth	Qty Per Box	Weight Kg Per 100	Price £ Per 100
0868M54HI	M8	10	80	9	-	80	10	1.0	134.56
0868M56HI	M10	12	90	11	-	100	10	1.4	143.20
0868M58HI	M12	14	110	13	-	120	10	2.5	166.62
0868M62HI	M16	18	125	17	-	160	10	4.0	204.20
0868M64HI	M20	25	175	22	-	200	6	10.0	331.19
0868M66HI	M24	28	210	24	-	240	6	14.2	420.74

For use with Rebar or Threaded Rod in concrete.



INTERNAL THREADED SOCKETS - Zinc

Code	Internal Thread Size	Length	Internal Thread Length	Outside Diameter	Hole Diameter	Min Hole Depth	Capsule Code	Qty Per Box	Weight Kg Per 100	Price £ Per 100
0868I54	M8	90	20	M12	14	90	0868M58SI	25	4.0	154.16
0868I56	M10	90	25	M16	18	90	0868M62SI	25	7.0	192.34
0868I58	M12	90	30	M20	25	90	0868M64SI	25	16.0	268.80
0868I62	M16	125	40	M20	28	125	0868M66SI	10	29.0	548.33

Permanent threaded sockets for use with glass capsules or injection resins. It has an internal threaded socket for use with bolts or threaded rod of any length. Use tool when using with capsules.



INTERNAL THREADED SOCKETS - Stainless Steel A2 (A4 Available on request)

Code	Internal Thread Size	Length	Internal Thread Length	Overall Diameter	Hole Diameter	Min Hole Depth	Capsule Code	Qty Per Box	Weight Kg Per 100	Price £ Per 100
0868I54SS	M8	90	20	M12	14	90	0868M58SI	25	4.0	398.17
0868I56SS	M10	90	25	M16	18	90	0868M62SI	25	7.0	564.07
0868I58SS	M12	90	30	M20	25	90	0868M64SI	25	16.0	796.33
0868I62SS	M16	125	40	M24	28	125	0868M66SI	10	29.0	1539.58

Permanent threaded sockets for use with glass capsules or injection resins.

It has an internal threaded socket for use with bolts or threaded rod of any length.

Use tool when using with capsules.




Technical Information

CURING TIMES FOR DRY HOLE INSTALLATION:


Concrete Temperature °C	HAMMER-IN CAPSULES		SPIN-IN CAPSULES	
	Curing Time (mins)		Curing Time (mins)	
over 20	60	10		
10 - 20	120	20		
0 - 10	300	60		
-5 - 0	600	300		

CURING TIMES FOR DAMP HOLE INSTALLATION:


Concrete Temperature °C	HAMMER-IN CAPSULES		SPIN-IN CAPSULES	
	Curing Time (mins)		Curing Time (mins)	
over 20	60	20		
10 - 20	240	40		
0 - 10	600	120		




Drill your hole to the correct diameter...



...clear any debris...



...hammer in the stud to the bottom...



...allow the recommended cure time.